

UNLOADING SPANDREL PANELS WITH Fork & Short Strap – Safety Sheet MS100b



Safety Sheet MS100b - 01/02/2016 - Rev0







The contractor is responsible for the provision of lifting equipment , a qualified operator and the Slinger / Banksman. After parking on site the driver inspects the load ensuring it is still secure, with all banding & / or rope in place. Once inspected the driver must sign in at the site managers office. Level unloading areas are essential

as Spandre Panels due to their weight and height may be unstable once straps removed. Tie down straps should not be removed from load until mechanical unloading equipment is available and unloading is ready to commence. Driver will release the load on customer instruction.



Safety Sheet MS100b - 01/02/2016 - Rev0

Safety Sheet MS100b - 01/02/2016 - Rev0

### 3. Multiple Section Panels

When Panels are delivered in multiple sections, installed slings are intended to lift only the panel section to which they are attached as delivered. Panels are intended for in-situ assembly only i.e. at their final location post lifting.



# 4. Slings

Drivers and site staff are not permitted to access lorry bed during unloading. Spandrel Panels will arrive pre-slung with appropriate lifting slings. It is recommend Forked equipment is fitted with appropriate Crane Hook attachment. Where not available, forks must be inspected for sharp edges

to protect straps from damage during lifting. Alternatively fork sheaths or other appropriate protection shall be used.



#### 5. Attachment

A number of options are

- available:a) Straps are lifted over forks using telescopic
- pole.
  b) An additional heavy duty load strap is threaded through installed slings and the slinger can then attach the heavy duty strap to the lifting equipment.
- c) Steel Stillage frames can be lifted directly from vehicle using forks.



Safety Sheet MS100b - 01/02/2016 - Rev0

### 6 Lifting

The Lifting equipment will then take up the slack of the lift. On instruction from the site responsible person the driver will release the transport straps on the side being unloaded. Guide ropes may also be attached to pre-installed straps along bottom chord.



Safety Sheet MS100b - 01/02/2016 - Rev0

### 7. Release Panel

The Lifting equipment will then take up any further slack of the lift. The driver will cut the individual rope / banding attaching the panel to the vehicle centre bars. This must be carried out from a safe position using a telescopic cutting staff.



Safety Sheet MS100b - 01/02/2016 - Rev0

#### 8. Safety Area

Forked equipment will then lift the panel from the bed of the trailer. Given the weight and shape of panel it is essential that the danger area in front of the panel is kept clear of all personnel. NEVER stand in the danger area where the panel could potentially fall or swing. Do not allow any others to enter the danger area.



Safety Sheet MS100b - 01/02/2016 - Rev0

## 9. Further Information

Spandrel Panels are wrapped for weather protection and require specifically designed storage racks. If they are not being installed immediately. Seek further information from Supplierre appropriate storage. If weather protection wrappings are damaged or removed before final installation then the dry timber and cladding materials used may be prone to water damage significantly reducing performance of fixings and potentially increasing the overall weight of panels. If water damage has occurred no attempt should be made to lift the panel using the preinstalled lifting straps.



TRUSSED RAFTER<br/>ASSOCIATIONImage: Constraint of the cons

Safety Sheet MS100b - 01/02/2016 - Rev0